
brunner::



cellular Assembly instructions Design: Archirivolto

Thank you for buying a quality Brunner product from the cellular series. The versatile furniture in our cellular range is perfect if you are looking to furnish small quiet areas and workspaces in large halls and waiting areas. Available with or without panels, these versatile chairs and benches can be used in a myriad of ways.

Thanks to the 60° angled construction of the work and lounging units, they can be set out in groups, lines or circles, making best use of available space. Side tables that can be flexibly positioned make for the ideal addition to the range.


If upholstered easy chairs, work tables or standing tables are ordered with panels, the panels have to be fitted on site. These assembly instructions provide an explanation of all of the key components and will help you assemble your cellular furniture with ease.


CELLULAR ASSEMBLY INSTRUCTIONS


Contents


- 4 Overview of variants
- 6 Scope of delivery of upholstered easy chair with panels CE1100
- 7 Scope of delivery of upholstered sofa with panels CE2300
- 8 Assembly instructions for upholstered easy chair and sofa with panels
- 12 Scope of delivery of desk with panels CE1070
- 13 Scope of delivery of desk with panels CE1080
- 14 Scope of delivery of desk with panels CE4010
- 15 Scope of delivery of desk with panels CE4030
- 16 Scope of delivery of desk with panels CE3100
- 17 Scope of delivery of desk with panels CE3200
- 18 Base and panel pre-assembly
- 19 Assembly instructions for desk with panels
- 26 Further information
- 26 General information about assembly
- 26 Recommended assembly tool
- 27 Care instructions
- 30 Notes
- 30 Imprint


OVERVIEW OF VARIANTS
















SCOPE OF DELIVERY OF UPHOLSTERED EASY CHAIR WITH PANELS CE1100

Included in scope of delivery:


12 x 5x30 Spax screws




1 x M5x35 screws



1 x left-hand panel



1 x easy chair




4 x brackets



4 x M5x16 screws



1 x right-hand panel



SCOPE OF DELIVERY OF UPHOLSTERED SOFA WITH PANELS CE2300

Included in scope of delivery:


21 x 5x30 Spax screws




2 x M5x35 screws



1 x left-hand panel






7 x brackets




7 x M5x16 screws




1 x right-hand panel



1 x sofa




ASSEMBLY INSTRUCTIONS FOR UPHOLSTERED EASY CHAIR AND SOFA WITH PANELS



ASSEMBLY STEP 1


Hook the right-hand panel into the pre-assembled fixture on the back right of the upholstered easy chair, taking care not to press down.



ASSEMBLY STEP 2


Then, hook the left-hand panel into the corresponding fixture on the back left of the upholstered easy chair, again taking care not to press down.

ASSEMBLY INSTRUCTIONS FOR UPHOLSTERED EASY CHAIR AND SOFA WITH PANELS



ASSEMBLY STEP 3


Gently push the top edges of the two panels apart and position the M5x35 screw in the corresponding thread in the lefthand panel. Tighten the screw until it is approx. 10 mm away from the panel.



ASSEMBLY STEP 4


Now lift the right-hand panel up slightly and hook the screw from the left-hand panel into the recess in the right-hand panel to attach them to one another.

ASSEMBLY INSTRUCTIONS FOR UPHOLSTERED EASY CHAIR AND SOFA WITH PANELS



ASSEMBLY STEP 5


Now push the two panels down so they are anchored in the fixtures on the upholstered easy chair.



ASSEMBLY STEP 6


Carefully tip the upholstered easy chair back together with the panels and place the furniture on a soft and clean surface, such as a blanket. Position the four brackets at the recommended points between the lower edge of the upholstery and the panel. Fix in position on the panel using an M5x16 screw.

ASSEMBLY INSTRUCTIONS FOR UPHOLSTERED EASY CHAIR AND SOFA WITH PANELS



ASSEMBLY STEP 7

Push the panel to the side of the upholstered easy chair and align the bracket with the chair. Fasten the four brackets to the base of the upholstered easy chair using three 5x30 Spax screws for each. Make sure the first panel is fastened before moving on to the second panel.



Included in scope of delivery:











1 x connecting hook









4 x M6x45 screws




1 x table top



1 x left-hand panel



1 x right-hand panel



1 x front left foot



1 x back centre foot





1 x front right foot





1 x cross-brace






















Affix the connecting hook to the pre-drilled place on the base. Secure with screws (M5x16).




Affix the panel attachment to the pre-drilled place on the panel. Secure with screws (M6x45).

The following steps also apply to models CE1070, CE1080, CE4010, CE4030, CE3100 and CE3200




ASSEMBLY STEP 1

Insert the legs into the recesses provided on the table and tablet and secure them using the SeKo M6x18 screws provided.




ASSEMBLY STEP 2

To connect the table to the tablet, stand the table up and place the tablet on the protruding base. Then tighten all the screws.




ASSEMBLY STEP 3

To install the panels, place the panel so that the plastic block on the inside of the panel is level with the front leg of the table. Slide the plastic block into the groove on the table leg. You can then put the screws (LiFlaKo M6x25) in the upper section of the table leg and screw them lightly. Please do not tighten the screws yet.




ASSEMBLY STEP 4

All of the other panels are assembled in the same way. Hook the next panel onto the first one fitted then use the screws to secure to the table legs and tighten slightly.




See assembly step 4



ASSEMBLY STEP 5

Fitting the reinforcement slat underneath the table top. Use the 2 x SeKo M8x20 screws to screw the reinforcement slat to the table legs and tighten with RuKo Spax 4.5x13 on the table top.




ASSEMBLY STEP 6

The inserted plastic blocks can now be tightened. Tighten the still loose connection first with a screw clamp then, using a drill, drill a hole (5 mm in diameter) in the plastic block and secure it to the table leg with an M6x16 screw. All of the other still loosely positioned screws can then be securely attached.

GENERAL INFORMATION ABOUT ASSEMBLY

The assembly instructions provide general guidelines for assembling your cellular furniture

- ·The steps described are to be followed for all cellular chairs and tables
- \cdot The assembly tools suggested are simply recommendations from Brunner GmbH
- · Only the materials supplied may be used for assembly
- · Brunner GmbH accepts no liability for damage caused during assembly



ASSEMBLY TOOL FOR CELLULAR FURNITURE

Cordless screwdriver with hexagon and cross insert plus screw clamp and drill bit measuring 5 mm in diameter

CARE INSTRUCTIONS

Careful and proper cleaning of the surfaces of your cellular table is particularly important to keep it in optimum condition for as long as possible. The following cleaning instructions are only intended as a recommendation. Brunner GmbH will not be held liable for damage to the finish caused by improper cleaning.


Cleaning the powder-coated steel tube frame



For normal use, it is sufficient to wipe the metal surfaces with a clean, dry dust cloth. Any particularly dirty areas can be cleaned with a standard, greasedissolving all-purpose cleaner. Please only use soft cotton cloths for cleaning purposes and never use plastic sponges, wire wool or steam jet devices, which could permanently damage the surface. Never use abrasive cleaning agents or toilet or sanitary cleaners. The gliders' surfaces should be regularly cleaned of coarse pieces of dirt or deposits. External factors, such as weight and humidity, can cause the gliders to wear out or slip. Coarse dirt and deposits should be removed from them regularly. The usual level of care is required when replacing the gliders.

Cleaning cover fabrics

Upholstered surfaces need regular care as they constantly come into contact with dust and dirt. In general, soiling should not be allowed to build up too much or be left too long in order to avoid making cleaning more difficult and to extend the life of the product.



Clean fabric covers from the Brunner standard range using an upholstery brush or a vacuum cleaner attachment suitable for cleaning upholstered furniture. Depending on the level of soiling, it may be advisable to use a soft, damp cloth and a little detergent.

For more information about cleaning fabrics, see the fabric cards for the fabric collection in question.

Please note that some dark fabrics can cause staining. The fabric colour of clothing can be transferred onto the upholstery after coming into contact just once. The result is a permanent, non-soluble stain.



Regularly remove dust and light soiling from leather covers using a dry or slightly damp cloth. Gently rub dried-in dirt with a weak neutral soap solution and a soft cloth. Afterwards, wipe over to dry and apply a suitable leather care product while observing the manufacturer's instructions for use. Do not use solvents, cleaning petrol, stain removers, spirit, shoe cream or the like.

Imitation leather is best cleaned using a clean, slightly damp chamois cloth. Please note: Do not use care products for real leather. Resoiling often occurs due to the use of conventional household detergents and cleaning agents. When using cleaning agents, please observe the cleaning agent manufacturer's instructions for use and always test the suitability of the cleaning agent on a concealed area first to avoid discolouration or abrasion.

CARE INSTRUCTIONS



General cleaning of table tops

As a general rule, we recommend cleaning with a lint-free cloth dampened with pure water without any added cleaning agents or furniture polish. Afterwards, dry off the surface of the table with a clean, soft cloth. Never use silicone-based polishes, strong ammonia, alcohol or plasticiser-based cleaning agents. The same applies to abrasive cleaning agents containing scouring agents.



Cleaning table tops with high-pressure laminate

Clean the surface with warm water and then dry it with a paper towel or soft cloth. For heavier soiling, such as adhesives or lacquers, organic solvents such as ethanol, acetone or nail varnish remover will be needed. The cleaning agent should not contain any abrasive ingredients, as they could lead to changes in the gloss level and scratches. We recommend leaving the cleaning agent to work as required depending on how dirty the surface is. Afterwards, wash off with water and dry. Remove any remnants of the cleaning agent to prevent streaks from developing. Please do not use wax-based furniture polish or cleaning agents, as they are inclined to build up in the texture of the HPL finish and result in a sticky, unattractive layer that attracts dirt.



Cleaning table tops with oak veneer

Clean regularly with a soft, lint-free cloth. With normal use, it is enough to remove dirt from the surface once or twice a year with a damp cloth. Use water mixed with a small amount of commercially available mild detergent to dampen the cloth. Then, while the surface is still damp, wipe it with a soft, clean cloth in the same direction as the wood grain. Avoid rubbing hard, as this can cause differences in finish to occur with matte surfaces. After lengthy and heavy use, the lacquered surface can be cleaned with a commercially available furniture polish. Please note when using the table that, if liquids are spilled on the surface, these must be wiped up immediately to avoid marks. Please refer to the applicable manufacturer's instructions for use and, where appropriate, check suitability in an area on your table that is not visible.

Notes

For details, prices, terms and conditions, refer to the current price list. We reserve the right to technical changes, errors and colour deviations. Some models are displayed as special versions that are subject to additional costs.

Imprint

Product design: Archirivolto

Illustrations:

Andreas Stapel . Brunner GmbH

Text

Brunner GmbH

Design:

Brunner GmbH

www.brunner-group.com

© Brunner GmbH 2019 . Im Salmenkopf 10 . 77866 Rheinau, Germany T. +49 78 44 40 20 . F. +49 78 44 40 28 00 . info@brunner-group.com